



# HTC HD2 Battery Replacement

Replace the battery in your HTC HD2.

Written By: Sam Luedloff



## INTRODUCTION

Use this guide to remove or replace the battery in the HTC HD2. The battery should be removed before working on any of the phone's internal components.

---



### PARTS:

- [HTC HD2 Compatible Battery](#) (1)
-

## Step 1 — Battery



- Carefully pull the rear cover from the back of the phone.
- Place a finger beneath the small lip on the left side of the battery.

## Step 2



- Lay the phone down on it's screen.
- Lift up on the lip and pull the battery from the phone.

To reassemble your device, follow these instructions in reverse order.

